


Wyred 4 Sound

Pure Music Quick Setup Guide


This guide will assist you to configure Pure Music for optimum performance with the DAC-2 DSD and DSDse. Please follow the steps below and refer to the screenshots for visual assistance.

Please note: Pure Music does not require that you set the output device in the Audio MIDI player


1. Launch Pure Music by clicking the icon on your dock. It is also possible that the icon for Pure Music is located in your applications folder. Once Pure Music is launched, it will automatically open iTunes. After the program opens you should see the screen below. For optimum performance we suggest that you enable **Memory Play** by clicking the button on the lower left side of the window. It will illuminate green once it is activated.




- Next, you will need to configure the output device. Click in the top portion of the Pure Music menu at which point you will see **Pure Music** listed on the top bar of your Mac desktop next to the apple. Click on **Pure Music** and select **Audio Setup** from the drop down menu to launch the audio settings menu. Please see image below.



- After launching the Audio setup, you will need to select the DAC as the output device. Use the drop down menu and select **32bit 384kHz DSD Interface** from the drop down menu. Next, select **Click to Apply Changes (Application Will Relaunch)** which is located near the bottom of the window and Pure Music will shut down and then re-open. At this point, the DAC is now selected as the output device.




- It is now necessary to set Pure Music to output to the DAC for DSD playback. Navigate back to the Audio setup menu by following the instructions in step 2 above. Click on the **Special Options** tab which is near the top of the window. Click on **Copy Current Output Device Name** to configure Pure Music to output DSD to the DAC. Ensure that the check box for **05FA** is selected in order send the DSD data in the proper format. The last step is to click on **Click to Apply Changes (Application Will Relaunch)** in order to apply the new settings.




You are now ready for playback!

- This last step is optional. We recommend disabling the DSP options in order simplify the appearance of Pure Music and to avoid unintentionally changing gain settings, etc. Click in the top portion of the Pure Music menu at which point you will see **Pure Music** listed on the top bar of your Mac desktop next to the apple. Click on **Music Server** and select **Disable DSP Options**.



Your main screen should now look similar to the image below. Setup is now complete!



If you have any questions please don't hesitate to email support@wyred4sound.com or call 805-466-9973.